Programming Basics

...learning the rules




Universal Rotary


What is Universal Rotary?

The Universal Rotary program type is designed to operate on any 4 or 5-axis Hurco machine - regardless of the axis configuration.

The control will make the necessary movements based on the axes it has available.

Universal Rotary






Simply program the tool as it would move around the part. <u>DO NOT</u> think about which axis would move on the machine.

Rotation Directions

...ISO standard & the right hand rule




ISO vs. Non-ISO Rotary




- There are two expressions that determine positive and negative rotations when programming rotary movements: ISO Standard & Non-ISO
- ISO is an Acronym for the International Organization for Standardization (ISO 841:2001)
- Non-ISO is the exact opposite
- Programming rotations are always ISO standard regardless of machine setting

ISO vs. Non-ISO Rotary



- There are two expressions that determine positive and negative rotations when programming rotary movements: ISO Standard & Non-ISO
- ISO is an Acronym for the International Organization for Standardization (ISO 841:2001)
- Non-ISO is the exact opposite
- Programming rotations are always ISO standard regardless of machine setting


The Right Hand Rule



The Right Hand Rule

Lay the thumb along the positive direction of the linear axis, and the fingers wrap in the positive direction of rotation of the tool.

The right hand rule always describes the ISO Standard rotary direction




Thank You!




Programming 5-sided

...how easy is it? ...can I do it?






Right Side




Right Side



Right Side


- 1. Move the origin point
- 2. Rotate the workplane




Right Side

- 1. Move the origin point
- 2. Rotate the workplane
- 3. Program 3-axis features


Right Side




Right Side




Right Side




Right Side






2. Rotate the workplane




G0 X2.566 Y1.3582 HURCΦ°


G68.2 X3.0 Y-3.0 Z-6.0 B90




2. Rotate the workplane




G0 X2.566 Y1.3582







3. Program 3-axis features



Conversational - OR - G Code


```
%
O2012(HURCO ENGRAVE)
(MATERIAL - ALUMINUM INCH - 2024)
(T1000 | 1/8 BALL ENDMILL)
N100 G20
N102 G0 G17 G40 G49 G80 G90
N104 T1000 M6
```





Conversational - OR - G Code

X1.56 Y2.1224 G53 Z0 G69 G0 A0 B0 M30



Repeat...


Repeat...

Repeat...


Thank You!




...do it by the numbers





PROGRAM REVIEW SCREEN			
DATA BLOCKS		SUB	BLOCKS
1. ROTARY POSITION			
END OF PROGRAM			








- Start every program with a Rotary Position Block
- Ensures that the tilting and rotary axes are at a known location before starting the program
- Almost always leave the data to the default values





















Thank You!





Controlling the Direction


...chamfer with end and side of endmill



























BLOCK 2	MILL FRAME			
GEOMETRY	CORNERS			
X CORNER	-0.2500	Z START	0.5000	
Y CORNER	-0.2500	Z BOTTOM	0.0000	
X LENGTH	1.0000	CORNER RADIUS	0.0000	
Y LENGTH	6.5000			





BLOCK 2	MILL FRAME		
GEOMETRY	CORNERS		
X CORNER	-0.2500	Z START	0.5000
Y CORNER	-0.2500	Z BOTTOM	0.0000
X LENGTH	1.0000	CORNER RADIUS	0.0000
Y LENGTH	6.5000		











































































Cutter Comp to Control Location













Thank You!





...when it's not at 90°

















Thank You!




...controlling orientation











...either way

































2. Rotate the workplane







2. Rotate the workplane





2. Rotate the workplane





BLOCK 7	MILL TRUE-T	YPE LETTERING	
X REFERENCE	3.0000	Z START	0.1000
Y REFERENCE	3.0000	Z BOTTOM	-0.0150
TEXT WIDTH	5.0000	ORIENTATION	0.000
TEXT HEIGHT	1.1250	MAPPING	BODY ONLY
WIDTH REF LOC	CENTER -		
HEIGHT REF LOC	CENTER -	FONT Arial	
TEXT HURCO			
ROUGHING FIN	ISHING SFO) ALLOWAN	ICES
T00L	3 EN	D MILL, dia. 0.	0620
MILLING TYPE	ON -		
MILL FEED SPEED (RPM)	0.0	PECK DEPTH PLUNGE FEED	0.0000

Thank You!

