


Navigating the Control Console Orientation

Console Orientation




Calculator Keys:

- **Math Functions**
 - All numerical data in the control can be entered as a math function.
 - Convert from Metric to Inch as the number is entered.

Drawing Graphics:

- **Draw**
 - Displays the current program toolpath on the graphics screen


Console Orientation



Menu Keys:

- **Input**
 - Part Setup; Tool Setup; Program; Program Parameters
- **Review**
 - Program navigation; insert blocks
- **Auxiliary**
 - Special screens and quick-keys
- **Help**
 - On-screen help file
 - Current content related


Console Orientation



Manual Function Keys:

- Spindle ON/OFF
 - Starts the spindle manually
- Tool Changer
 - Initiates a toolchange
- Coolant Keys
 - Auto – uses tool setup setting
 - Primary – Flood Coolant
 - Secondary – Thru Spindle Coolant


Console Orientation



Machine Modes:

- Auto
 - Conversational or NC
- Interrupt
 - Semi-Manual Mode
- Single Block
 - Executes one block with cycle start
- Optional Stop
- Manual
 - Manual Function Setup
 - Tool Management


Console Orientation



Edit Keys:

- Cursor Arrows
 - Previous & Advance
 - NOT Left & Right
- Basic Edit Keys
 - Insert & Delete
 - Home & End
 - Page Up & Down


Console Orientation



Override Pots:

- Axis Feed Rate
 - 0% to 150%
- Rapid Override
 - 0% to 100%
 - % of Program Parameter Setting
- Spindle Override
 - 0% to 150%

Console Orientation



Important Control Buttons:

- **Input**
 - Part Setup; Tool Setup; Program; Program Parameters
- **Manual**
 - Manual Function Setup; Tool Management
- **Review**
 - Program navigation; insert blocks