

Offshore personnel transfer basket Servicing Schedule



Type of service		When is it needed?	Why is it needed?	Who can do it?
Regular	Wire-Rope Lifting Assembly Replacement	Every 12 months as minimum for low usage units.*	This is a critical safety component the most susceptible to damage. The wire-rope lifting assembly must be replaced irrespective of its apparent condition. Due to anti-rotation construction of the wire rope, it is difficult to inspect it thoroughly.	A crew member with Reflex Marine Training Certificate or a Reflex Marine Trained Technician at one of the Approved Service Centres.
	Critical Parts Replacement	FROG, FROG-XT, TORO: every 3 years as minimum for low usage units.* WAVE-4: every 4 years as minimum for low usage units.*	These critical components must be replaced regularly to ensure the unit is fit for use.	
	Suspension System Replacement (FROG, FROG-XT and TORO)	Every 4 years as minimum for low usage units.*	This component should be changed out regularly to ensure the suspension is working at optimal performance.	

*more frequent maintenance is required for higher usage units: check your User Manual for details.

***Always refer to your product's User Manual for more detailed recommendations for your unit.**

If in doubt, contact Reflex Marine to clarify.

For more information visit www.reflexmarine.com or email info@reflexmarine.com.