

# TOOL TOUCH OFF WITHOUT A PROBE

## Instructions:

Note: the tool setup and touch-off procedures assume that the machine control has been setup in Absolute Tool Length mode.

### Verify Active Device

1. Press INPUT on control panel
2. Select TOOL REVIEW softkey
3. Select TOOL SETUP softkey
4. Select MORE softkey
5. Select TOOL MEASUREMENT SETTINGS softkey
6. Select the active Touch-off device

### Calibrate the Tool

1. Jog the tool into contact with the active touch-off device using the hand-wheel
2. Store the tool length by pressing the SET LENGTH softkey (F6)