

Using Wire Cleaning / Lube Pads



For Solid or Flux Core Steel Mig Wire

- Use a (Red) Cleaning pad nearest your wire spool & a (Black) Lube pad nearest your wire feeder.



For Aluminum Mig Wire

- Use only a (Red) Cleaning pad between wire spool & wire feeder.

