

# Exploded View/Parts List

## MYS-20 Exploded View/Parts List


### ⚠ CAUTION

- Users should never perform disassembly of the tool.

This illustration is for reference only.

For repair or replacement of the tool, request service from the retailer where you purchased the tool or the nearest NITTO service member store.

Exploded view/parts list are subject to change at any time without notice. (As of Sep. 2017)



\*1 indicates a consumable item, \*2 indicates a commercial item. Parts inside ( ) are components of the above assembly.

No.	Part no.	Part name	Quantity
*1 *2	1	TQ12638 Needle Bearing BK0609T2	1
*1	2	TQ12986 Gear 1×22	1
*1 *2	3	TP00498 Ball Bearing 6001ZZ	1
	4	TB08597 Bearing Set Screw Ass'y	1 set
	5	TB09777 Spindle Sub Ass'y	1 set
	(6)	(TP10742) Chuck Nut	1
	7	TP10110 Cap	1

Exploded view/parts list are subject to change at any time without notice. (As of Sep. 2017)

No.	Part no.	Part name	Quantity
*1 *2	8	TP03933 Ball Bearing 606ZZ	1
	9	TP10109 End Plate A	1
	10	TP00496 Spring Pin 2.5×6 AW	1
	11	TP14222 Cylinder	1
	12	TP14224 Rotor	1
*1	13	TB08602 Blade Ass'y (4 pcs.)	1 set
	14	TP06322 Spacer 8×11×3	1
	15	TQ12622 End Plate B	1
*1 *2	16	TP00468 Ball Bearing 608ZZ	1
*1	17	TQ12985 Pinion 1×15	1
	18	TB10384 Housing Ass'y	1 set
	(19)	(TQ15260) Label Warning	1
	20	TQ15004 Plug 20	1
	21	TQ14950 + Countersunk Head Screw 4×16	1
	22	TQ14889 Exhaust Cover	1
	23	TQ14949 Spacer	1
	24	TQ14891 Packing Cover	1
*1	25	TQ15131 Exhaust Filter	1
	26	TP10098 Lock Nut	1
	27	TP03468 Lock Ring	1
	28	TB10383 Valve Body Sub Ass'y	1 set
	(29)	(TQ15265) Label Specification	1
	30	TA93070 Valve Stem Ass'y	1 set
	31	TP06325 Adjust Valve	1
	32	TP11997 O-Ring KS-7	1
	33	TP06326 Spacer 6×12×1.2	1
	34	TP03695 Internal Retaining Ring C-12	1
	35	TB01152 Lever Ass'y	1
	(36)	(TP00460) Spring Pin 3×22 AW	1
	(37)	(TP05498) Spring Pin 2×16 AW	1

#### Accessories

No.	Part no.	Part name	Quantity
	TQ14382	PAD 2"	1
	TQ14383	PAD 1-1/2"	1
	TQ14384	PAD 1"	1
	TQ14358	Abrasive Disc 1" × #60	2
	TQ14359	Abrasive Disc 1" × #80	2
	TQ14360	Abrasive Disc 1" × #100	2
	TQ14361	Abrasive Disc 1" × #120	2
	TQ14366	Abrasive Disc 1-1/2" × #60	2
	TQ14367	Abrasive Disc 1-1/2" × #80	2
	TQ14368	Abrasive Disc 1-1/2" × #100	2
	TQ14369	Abrasive Disc 1-1/2" × #120	2
	TQ14374	Abrasive Disc 2" × #60	2
	TQ14375	Abrasive Disc 2" × #80	2
	TQ14376	Abrasive Disc 2" × #100	2
	TQ14377	Abrasive Disc 2" × #120	2
	TP02236	Bushing R 1/4 × NPT 1/4	1
	TP00475	Spanner 14	2
	TQ15266	Instruction Manual	1