




ADJUST

SWIFTSPACE

www.swiftspaceinc.com



1. Worksurface

Top is 1-inch thick with a 2mm edge for durability. It is constructed with a high-pressure laminate surface with a particle board core. The worksurface can be ordered in a rectangular or kidney shape in any width from 40" to 60" with a depth of 24", 30", or 36". The worksurface is available in any of our Swiftspace standard laminates or optional whiteboard surface.

2. Counterbalancing

The lifting mechanism can be adjusted by the user to allow the table to lift effortlessly with any weight between 30 and 100 lbs on the surface. The mechanism can handle weights of up to 500 lbs. For any weight above 100 lbs the item must be removed from the surface before the lifting mechanism is engaged.

3. Castors

The casters are 2.5" in diameter with grey rubber wheels that swivel and lock.

4. Power and Data

The Swiftspace standard powerbar can be added under the surface to give access to amps of power and a 15 ft powercord that can be plugged into any regular receptacle. An optional power/data trough can be added to allow for the installation of the Swiftspace. 4-circuit 80 amp powersystem. Underneath the surface is a raceway for the data cables and our Trac4 power system if additional power is required.

5. Height Adjustment

The height-adjustable dual arm mechanism raises the worksurface from 26" to 48" in height. The pneumatic height adjustment is infinite throughout its vertical range. At all times the worksurface maintains a level position. Once the preferred working height is attained the user releases a handle and the mechanism locks into place. To avoid pinch points, the worksurface remains a safe one inch from the desk frame at all times.

6. Accessories

Various accessories are available. such as privacy panels, in various materials, accessory rail with add-ons, monitor arms, keyboard arms and trays, electrical add-on, CPU holder.

Our Adjust Stations,

- Ships fully assembled
- Requires no installation
- Are mobile, making them easy to reconfigure
- Requires no power to adjust the worksurface height
- Can be easily inserted into any other Swiftspace fixed-height producer to give a height adjustable solution

For more information about our products or to schedule a demo visit www.swiftspaceinc.com

