WEBS-MT/R-OP5 AND VOIP-500/600 SYSTEM LEVEL INTERFACE

Drawn By: J. Rounds
Revision: 1.4
Revision Date: 01/23/2017

= To DIN Rail

= To Other Component

"White" color cables in the physical wiring assembly are indicated as "pink" color cables in the schematic.

*Not provided by TALKAPHONE

† The WEBS-PSU power supply is used inside a WEBS-MT/R (120VAC) tower to convert the external 120VAC, 50Hz source to 12VDC. When using our WEBS-BACKUP or the WEBS-MT/R (12VDC) tower, connect the 12VDC supply to the terminal block as indicated

TALKAPHONE

7530 North Natchez Avenue
Niles, Illinois 60714
773.539.1100
Talkaphone.com