

LOAD A CONVERSATIONAL OR NC PROGRAM INTO YOUR CONTROL VIA USB

Instructions:

Note: Follow these instructions each time you insert a new USB into the machine so the control can read the USB: 1. Click the minus sign [-] next to the "computer" icon on the control to collapse the menu items. 2. Click the plus sign [+] next to the "computer" icon on the control to expand the menu items. This applies to each USB port.

Loading an NC Program:

1. Load a USB into the Hurco control
 2. Press the PROGRAM MANAGER softkey
 3. Press the OPEN softkey
 4. Select the program you are wanting to import
 5. Press the LOAD softkey
- If you wanting to view your NC program immediately:
6. Press the INPUT key
 7. Select PART PROGRAMMING

Loading a Conversational Program:

1. Load a USB into the Hurco control
 2. Press the PROGRAM MANAGER softkey
 3. Press the OPEN softkey
 4. Select the program you are wanting to import
 5. Press the Load softkey
- If you are wanting to view your conversational program immediately:
6. Press the REVIEW key