

VERSION 1.0 DRAFT 20.10.2021

FLYABILITY SA +41 21 311 55 00 — INFO@FLYABILITY.COM EPFL INNOVATION PARK BLDG C | 1015 LAUSANNE | SWITZERLAND



Table of content

1	Before starting	3
2	ELIOS 2 RAD System	3
3	Elios 2 RAD	4
4	ELIOS 2 RAD detector module	4
4.1	Out of range behaviour	4
4.2	Specifications	5
5	Cockpit Interface	6
6	Post flight analysis with Inspector 3.0	7
7	Calibration	8
7.1	Setting up RiumConfig	8
7.2	Calibrating the Elios 2 RAD sensor module	9
8	Technical Specifications	11
9	ELIOS System transmitted Power1	4



1 Before starting

This manual focuses on the features of the dosimetry payload of Elios 2 RAD. It complements the following documents, which the Elios 2 RAD user must also read and understand fully:

- ELIOS 2 Original Instructions certification compliance, safety guidelines and checklists
- ELIOS 2 User Manual complete user guide
- ELIOS 2 Smart Battery Guidelines safety guidelines

2 ELIOS 2 RAD System

The Flyability ELIOS 2 was developed explicitly as a flying platform capable of entering confined and cluttered environments. Elios 2 RAD is equipped with an additional dosimetry sensor.



Figure 2.1: System overview

The operator will enjoy full control of Elios through the Ground Control System (GCS). A tablet allows the operator to monitor a live video feed and instantaneous dose rate transmitted by ELIOS 2. RAD The Flyability Inspector post-mission analysis software provides a simple solution to visualize the recorded video, the thermal video and dosimeter data. Inspector 3.0 premium allows the user to recreate a 3D image of the flight environment to better visualize the dose rates measured in various locations.



3 Elios 2 RAD



Elios 2 RAD is a specially modified Elios 2 designed to carry a dosimetry detector module. Apart from the mounting bracket for the detector module, and the modified casing with a connector, all user changeable parts are compatible with a standard Elios 2. There is no significant change in flight behaviour and collsion resilience, though flight time is reduced slightly due to the added weight of the sensor module.

4 ELIOS 2 RAD detector module



This module allows Elios 2 RAD to measure ambient radiation. At its core, the sensor module has an energycompensated Geiger-Müller tube capable of detecting both Gamma and X-rays.

The sensor module is removable for calibration, but can only be installed on the specially modified Elios 2 RAD drone. To remove the sensor, undo the straps that hold in it place, and disconnect the cable that plugs into the body of the drone.

Elios 2 RAD is shipped with three detectors, each detector is designed for a specific dose rate range

4.1 Out of range behaviour

The Elios 2 RAD detectors will provide accurate readings within their specified range. Below a certain threshold it will display zero, with occasional spurious. Such readings serve as an indicator that the detector is still operational, but the values should be ignored, and it can be assumed that the actual dose rate is lower than the threshold level.

Above the maximum range the detector reaches its saturation point, above this value, the reading will continue to rise but it will no longer be accurate.



4.2 Detector Specifications

HIGH LEVEL RADIATION DETECTOR

Detector technology Types of radiation detected Calibration Energy Angular response H*(10) dose rate range – 10k Sensitivity Dose sensitivity Energy-compensated Geiger-Müller Gamma, X-ray Cs137 <30% over 180° 1.5 mSv/h – 10 Sv/h @ 1 to 2 second sample rate 0.006 cps/uSv/h < 0.1 µSv

MID LEVEL RADIATION DETECTOR

Detector technology Types of radiation detected Calibration Energy Angular response H*(10) dose rate range – 10k Sensitivity Dose sensitivity Energy-compensated Geiger-Müller Gamma, X-ray Cs137 <30% over 180° 8uSv/h - 1Sv/h @ 1 to 2 second sample rate 1 cps/uSv/h < 0.1 µSv

HIGH LEVEL RADIATION DETECTOR

Detector technology Types of radiation detected Calibration Energy Angular response H*(10) dose rate range – 10k Sensitivity Dose sensitivity Energy-compensated Geiger-Müller Gamma, X-ray Cs137 <30% over 180° 3uSv/h - 10mSv/h @ 1 to 2 second sample rate 2.6 cps/uSv/h < 0.1 µSv



5 Cockpit Interface

The dosimetry data is streamed directly to the ground station and can be monitored in real time on the Cockpit application.



DOSE RATE PLOT

A graphical representation of the dose rates measured over the past few seconds is displayed in the lower left corner (1).

DOSE RATE

The current dose rate is displayed below the plot (2)

TOTAL DOSE

The total dose absorbed by the drone since the battery is connected is displayed below the dose rate (2)

SETTINGS MENU

The cockpit setings menu contains the additional 'RAD SENSING'menu tab. This contains the following settings:



- 1. Unit, the unit in which the dose and dose rate are displayed, this can either be Sievert or Rem
- 2. Measured Value, the dose rate currently measured by the detector, updated every 2 seconds
- 3. Session Accumulated Dose, the total dose absorbed by the drone since the battery is connected
- 4. Lifetime Accumulated Dose, the total dose absorbed by the drone in it's lifetime before this session



6 Post flight analysis with Inspector 3.0

The flight data can be downloaded onto a PC using Inspector 3.0. The basic version allows the dosimeter data to be displayed alongside the video, while the premium version can re-create a 3D model of the flight environment, with the flight path being colorized corresponding to the locally measured dose rate values.



DOSE RATE GAUGE (1)

This gauge will display the dose rate at the current point in the video, and the total dose absorbed until that point in the flight. The user can choose whether the value is displayed in Sievert or Rem in the settings menu.

TRAJECTORY COLOR BAR (2)

This menu allows you to change the color mapping of the flight path line in the 3D model. By default it will autoscale from the minimum to the maximum value.

RADIATION TAB (3)

Click on this tab to expand a plot of the measured dose rate throughout the flight, this allows you to quickly identify hotspots





7 Calibration

The sensor module can be calibrated using the manufacturer's software by connecting the sensor module to a PC via the provided cable. The following softwares are required:

- 1. RIUMCONFIG calibration software, <u>available for free on the windows store</u>
- 2. The FTDI driver for the connection cable, <u>available here</u>

You will also need a license for the RIUMCONFIG software, this is a .csv file provided with the drone. If you do not have this file, then contact <u>support@flyability.com</u> and you will be given a new one free of charge.

7.1 Setting up RiumConfig

This software is developed by Icohup, the manufacturer of the detector unit. It can only be installed via the Windows Store. Follow the instructions to install it.

When launching the program you will be given the option to create a password (mot de passe means password). This is not needed for the Elios 2 RAD sensor module, but we recommend you do it anyways, because otherwise it will just keep bothering you with it. You may encounter parts of the program that are not translated, to help you we show you the main translated parts here below.

Choose Sensor:	Sélectionner votre capteur	~		Edit calibration report	DISCONNECT
	Network configuration			Warr Visual alarm	ning Thresholds - Channel A ? Audible alarm
	Add a wi	fi network		Dose rate (µSv/h) ⁷ :	Dose tate (µSv/h) ⁷ :
	SSID : Login : Password :			Warr	Centim
	A	dd		Visual alarm Dose rate (µSv/h) ⁷ :	Audible alarm Dose rate (µ5v/h) ⁷ :
				Dose (µSv) ? :	Dose (µSv) ⁷ : · · · · · · ·
	Name	Delete			
	Send	Pair with platform	1		
2°			↓		

To activate the license, click on "Pair with platform". This will open a window where you can select your .CSV license file. Once you have done this, restart the program. You will notice that there is no exit button, so you must press Alt+F4 to terminate it.

Start the program again. A second "calibration" button will have appeared on the left hand bar. You have successfully installed and activated RiumConfig.



7.2 Calibrating the Elios 2 RAD sensor module

Use the provided USB adapter to connect the sensor module to your PC.

In RiumConfig, click on the "Calibration" tab on the bar to the left, then select Elios-2 RAD from the drop down menu in the top left.

Choose Sensor:	Sélectionner votre capteur RiumOp		Edit calibration report	DIS	SCONNECT
	RiumBox	B∉ xoor	Channe	el B	BE XXX
Dose ra	RiumStick	Counting rate (c/s)	Dose rate (µSv/h)	Counting rate (c/s)	
Instant	Elios-2 RAD	3	instant	Instant	
Average	for seconds Average	for seconds	Average for seconds	Average for	seconds
	Start average measurement for 30	econds [†]	Start average measuremen	t for 30 seconds ²	
	Recalibration		Recall	ibration	
Theoretical dose rate (µS	Sw/h) ?	Calibration factor Current 1.5	Theoretical dose rate (µSv/h) ?	Calibration factor Current	1.5
		Suggested 5		7 Suggested	5
		Recalibrate		Recall	brate
	Spectrometry	Collection factor	Spectro	ometry Calibration faster	
List of isotopes		Current 1	List of isotopes	Current	1
Measured energy <		Suggested ?	Measured energy < >	Suggested 7	n
		Recalibrate		Recald	brate
Duration : 00:00:00 Nun	mber of events : 0 Jogarithmic scale	Export. RESET	Duration : 00:00:00 Number of events : 0	Uogarithmic scale	kt RESET

If the Elios 2 RAD sensor module is not connected to your PC at this point, then you will get this message

Suggested	Pas de ca Vérifier la con	pteur nexion du cap	teur et réessayez.				
Calibration fact			10000000	pes			
Current			Valider				
Suggested		9		hergy	< 1	>	
Re							
	Export	RESET					

This message means: "*No sensor, verify the connection and try again*". This can be due to a faulty connection, or due to the drivers not being installed correctly. Be sure that the FTDI drivers have been installed.

If the sensor module is successfully connected you will get a message saying "Confirmation de connexion", click 'Valider' to continue.

You can now calibrate the E2 RAD detector unit by making an average measurement and comparing it with the theoretical value of a known reference source. A suggested value for the calibration factor will appear in the field when you enter the theoretical dose rate of the known reference source.



Choose Sensor:	Elios-2 RAD 86-2E	~		Edit calibration report		DISCONNECT
	Channe	IA	Ba xxx	C	hannel B	ilit xxx
Dose Instant 0 Average 0.18	rate (µSv/h) for 1800 seconds Start average measurement	Counting Instant 0 Average 0 for for 1800 seconds ?	rate (c/s) 1800 seconds	Dose rate (µSv/h) Instant	Instant Average surremient for 30 set	Counting rate (c/s)
Theoretical dose rate (Recali usv/n) ? ad b	bration Calibratio Current Suggeste	n factor 1 d <u>1.11</u> Recalibrate	Theoretical dose rate (µSv/b) 7	Recalibration	Calibration factor Current 1.5 Suggested 7 Receipterate
				List of isotopes	Spectrometry	Calibration factor Current 1 Suggested 7
				Duration : 000000 Number of events : 0	toguthnic scale	Baport REST

When placing the detector module near the reference source, keep into consideration the slightly irregular directional response of the detector. The position of the GM-tube within the detector is marked on the housing.





8 Technical Specifications

AIRCRAFT	
CONFIGURATION	Quadcopter
DIMENSIONS	Fits in a < 400 mm sphere; 15.75 in
MOTORS	4 fast reversing electric brushless motors
MOTOR POWER RATING	120W average power 750W nominal peak power
PROPELLERS	4 propellers 5 inches
TAKE-OFF WEIGHT	< 1450 ar < 32 lbs
	Includes battery, navload & protection
MAX FLIGHT TIME	Lin to 10 min
MAX ASCENT SPEED	13 m/s: 43 ft/s
MAX DESCENT SPEED	13 m/s; 43 ft/s
MAX SPEED	13 m/s (Assist mode): (3 ft/s
	(1.5) (Assist Mode), 4,5 M/s
	4 m/s (Attimude), is it/s
MAX PITCH/ROLL ANGLES	0.5 m/s (sport mode)
	0.15 rad (Attitude Mode)
	0.2 rad (Assist Mode)
MAX WIND DESISTANCE	
MAX WIND RESISTANCE	5 m/s (Assist mode); 10 lt/s
	5 m/s (Sport mode); 16,4 m/s
	IMU, magnetometer, barometer, 7 vision and distance sensors
MATERIALS	Carbon fiber composites, magnesium alloy, aeronautical grade aluminum,
	nign-quality thermoplastics
OPERATING TEMP.	0 °C to 50 °C ¹ * (32 °F to 122 °F)
FLIGHT MODES	ASSIST - Assist mode
	ATTI - Attitude mode
	SPORT - Sport mode
FAIL-SAFE	Auto-landing on signal lost
	Forced-descent when battery critically low
OPERATING FREQUENCY	2404 – 2483 MHz (UAV to RC)
EIRP	2.4 GHz; < 32 dBm (FCC); <20 dBm (CE); <10 dBm/MHz (MIC)
INGRESS PROTECTION	Splash and dust resistant
NOISE LEVEL	99 dB(A) hover
	120 dB(A) max @ 1m
SMART BATTERY	
RATED CAPACITY	5200 mAh
NOMINAL VOLTAGE	19 V
BATTERY TYPE	LiPo 5S HV Smart Battery:
	- Improved safety (protection for: overcharge, overcurrent, over/under-
	temperature)
	- Plug-and-play charging
	- Self-balancing
	- Storage self-discharge
	- Cycle counter
	- Battery ID
ENERGY	98.8 Wh
CHARGING TIME	15 h
BATTERY CHANGE TIME	<1min
COMPLIANCE	Approved for carry-on luggage
	Complies with IATA Dangerous Cood Degulation
NET WEIGHT	550 g : 12 lbc
OPERATING TEMPFRATURF	JJV Y , 1.2 INS 0 50°C
	$0-30$ C and 10^{20} C and 10^{20} C and 10^{20} C and 10^{20} C c and $10^$
	auditional precautions must be taken between 0-10°C and 40-50°C. Stability,
CHARGING TEMPEDATURE	night performance and night time might be reduced.
	$IU = 4U^{*}U^{*}_{+} 5U^{*}F = II3^{*}F$
	ISU VA AU POWER
CHAROER	Ellos 2 Smart Battery Charger

¹Additional precautions must be taken between 0-10°C and 40-50°C. Stability, flight performance and flight time might be reduced.



PAYLOAD CHASSISPAYLOAD HEADDamped for vibrationsCAMERA POD UPWARD TILT+90 degreesCAMERA POD DOWNWARD TILT-90 degreesPAYLOAD PROTECTIONLoad limiting mechanism to protect the payload in the case of a frontal shock.

MAIN CAMERA	
SENSOR	1/2.3" CMOS
	Effective Pixels: 12.3 M
	Sensitivity: Optimized for low light performance
PHOTO FORMATS	JPG
VIDEO FORMATS	MOV
VIDEO RECORDING RESOLUTIONS	4k Ultra HD: 3840 x 2160 at 30 fps
	FHD: 1920 x 1080 at 30 fps
VIDEO STREAMING RESOLUTION	FHD: 1920 x 1080 at 30 fps or SD 640 x 480 at 30fps
MOVIE FOV	114° horizontal, 130.8° diagonal
PHOTO FOV	118.8° horizontal, 148.6° diagonal
TOTAL VERTICAL FOV	approximately 260° including camera tilt
LENS	2.71 mm focal length
	Fixed focal
CONTROL MODES	Auto mode with manual EV compensation
FILE STORAGE	MicroSD card (onboard the aircraft)
	Min Capacity: 64GB
	Max capacity: 128 GB
	Recommended model: Sandisk Extreme micro SDXC UHS-I V30
SUPPORTED FILE SYSTEM	exFAT

THERMAL CAMERA

SENSOR	Lepton 3.5 FLIR
VIDEO RECORDING RESOLUTION	160 x 120 at 9 fps
LENS	FOV 56° x 42°, Depth of field 15cm to infinity
SENSITIVITY (NEDT)	<50 mK
TEMPERATURE RANGE	-10°C to 140°C (14°F to 284°F)
WAVELENGTH (LWIR)	8-14 µm
FILE STORAGE SUPPORTED FILE SYSTEM	MicroSD card (onboard the aircraft) Max capacity: 32 GB Recommended model: Sandisk Extreme micro SDXC UHS-I V30 EAT32

LIGHTING SYSTEM

TYPE	High-efficiency LEDs for even lighting in front, top and bottom, optimized for
	low impact of dust on picture quality.
	IR light used for stabilization system.
CONTROL	From the remote controller, adaptive light beam controlled by camera pitch
MODES	Indirect/dustproof lighting
	Close up lighting
	Selective/oblique lighting
LIGHT OUTPUT	Max 10k lumens

OPERATION SAFETY AND CRASHWORTHINESS

NAVIGATION LIGHTS	Green (starboard) and red (port) lights.
PROTECTION CAGE	Carbon fiber cage with soft coating, modular subcomponents for maintenance ease, thermoplastic elastomer suspensions, front opening dimensioned for easy battery access.
COLLISION TOLERANCE	Uniform all around the drone, up to 3 m/s on flat objects, up to 1.5 m/s on sharp objects



	Remote controlle
REMOTE CONTROLLER OPERATING FREQUENCIES	2404 - 2483 MHz (RC to UAV) 5738 - 5808 MHz (RC to RC) 920.6 - 928 MHz (RC to RC, Japan only)
MAX TRANSMISSION DISTANCE EIRP WEIGHT OPERATING TEMP. OUTPUT PORT BATTERY CONTROLS OPTIONS BATTERY CHARGER	Up to 500 m in direct line of sight 2.4 Ghz ≤20 dBm, 5.8 GHz ≤13 dBm, 920 MHz ≤10 dBm 810 g (924 g with tablet holder) 0 °C to 40 °C HDMI, SDI, USB 6000 mAh 2S Aircraft control and payload settings Optional remote controller (camera operator) with video stream reception on a secondary screen, and dual control of camera settings. 17.4 V / 57 W
TABLET MODEL BATTERY CHARGER OPERATING TEMP. CHARGING TEMP. CHARGING TIME WORKING TIME WEIGHT	Samsung Galaxy Tab Active 2 USB Charger 5V -15 °C to 40 °C -15 °C to 40 °C 5 hours 5 hours (when receiving video stream) to 76 hours (idle) 415 g
TRANSPORT CASE DIMENSIONS WEIGHT COMPLIANCE	61 x 44 x 53 cm 11.5 kg IATA compliant for checked-in luggage.
COCKPIT SOFTWARE FEATURES	Real-time video and UAV telemetry, status visualization (remaining battery, payload settings, warnings, etc.), control payload settings and various
OPERATING SYSTEM	Android. Optimized for tablet provided with the ELIOS 2 system
INSPECTOR SOFTWARE FEATURES	Video and thermal video viewer (frame by frame), flight log analysis including point of interests recorded during flight, screenshots, and flight data export.
OPERATING SYSTEM	Windows 7, 8 and 10 (32 and 64 bits)



9 ELIOS System transmitted Power

ELIOS 2	
FREQUENCY BAND TX	2406 – 2476 MHz
MAXIMUM OUTPUT POWER	60mW, 18dBm in 2.4GHz band (CE mode) 456mW, 26.6dBm in 2.4GHz band (FCC mode)
DESIGNATION OF EMISSIONS	Digital bidirectional video and data downlink to remote controller, command and data uplink to to UAV
12011102001	OFDM, WIDEDAND
MODULATION TYPE	OFDM
E-FIELD STRENGTH	7.13V/m (measured at 20cm)
GCS	
FREQUENCY BAND TX	2404 – 2480 MHz 5738 – 5808MHz (CamOp, standard version) 920.6 MHz to 928 MHz (CamOp, Japan version)
MAXIMUM OUTPUT POWER	40mW, 16dBm in 2.4GHz band (CE and FCC mode) 6.3mW, 8dBm in 5.8GHz band (CE mode) 4.4mW, 6.4dBm in 5.8GHz band (FCC mode)
DESIGNATION OF EMISSIONS	Radio Video Downlink and telemetry and uplink of the from Drone
TECHNOLOGY	OFDM, wideband
MODULATION TYPE	OFDM

To comply with both FCC and CE standards concerning transmission power, the ground unit uses a GPS module to determine its geographic location and the power is adjusted accordingly. FCC mode is used in the following regions: USA, Canada, Mexico, Australia, Brazil, Taiwan. In other regions, or if no GPS position can be obtained, the system uses the more conservative CE standard.

Flyability S.A. Route du Lac 3 1094 Paudex Switzerland

Email: <u>support@flyability.com</u>

Content subject to change. Find the latest version on: www.flyability.com