



ANCHOR[®]

GO GETTER

BLUETOOTH INSTALLATION



REQUIREMENTS:

- 8,000 or series 2 Go Getter unit with I/O board at revision E (or newer)
- Screw drivers (Phillips #1 and #2)
- 8 mm Nutdriver





INSTRUCTIONS:

1. Make sure the unit is powered off and the plug is disconnected.



INSTRUCTIONS:

2. Remove the screws around the back panel.



INSTRUCTIONS:

3. Remove the back panel



INSTRUCTIONS:

4. Remove the battery and speaker harness
 - a. If applicable please remove the mic receiver harness



INSTRUCTIONS:

5. Remove the old Bluetooth module.



INSTRUCTIONS:

6. Remove the old harness from the Bluetooth module and use the included harnesses with the new Bluetooth module.



INSTRUCTIONS:

7. Connect the black and white audio cables to BT Audio.



INSTRUCTIONS:

8. Connect the red and black cables to BT only.



INSTRUCTIONS:

9. Reinstall the back panel to the unit and tighten with screws.