

A CLOSER LOOK

AC Auto-Balance™ Controls —
Automatically sets the optimal cleaning vs. penetration level for aluminum welding!

What Is It?

When aluminum welding, the positive (+) portion of the AC welding amperage cleans the oxides from the aluminum surface. The negative (-) portion delivers more heat input, increasing penetration level.


Patented AC Auto-Balance™ automatically sets the **ratio** of cleaning action (+) versus penetration (-) based on amperage.

Manual balance control provides the flexibility to customize the arc to your preference.



Easy Operation:

- Set it and forget it or override when you choose to customize the settings.



Proline 0800 699 353